

Easy Cut Lens Cutter™ Instructions

Important Information:

Completely read and follow all instructions before operating.

Each Easy Cut Lens Cutter™ offers free quality customer service. Contact Technical Support at 800-937-9593 if you need assistance.

Using the Easy Cut Lens Cutter™ The Easy Cut Lens Cutter comes fully assembled.

1. Remove Lens Cutter from packaging and place on a steady work surface.
2. To set the desired circle size, loosen screw located at the rear of the adjustable cutting arm and slide arm to desired cutting diameter; re-tighten screw (Diameter increments on base and cutting arm are in inches).
3. If desired, add an oil lubricant to the cutting wheel by simply dipping a paper towel into the lubricant and touch it to the cutting wheel.
4. Place your glass in the center of the Lens Cutter table. Glass should be slightly larger than the desired circle diameter.
5. Adjust the cutting wheel so that the blade is positioned on the bottom of the wheel and tighten with thumb screw (when dull, rotate the cutting wheel to another blade).
6. While holding the black knob above the cutting wheel, press down so the cutting wheel touches the glass. Rotate the knob till the whole circle has been scored once. *Do not go over score when done.*
7. With a hand glass cutter, add additional score lines that radiate from the circle as shown in Diagram 1. Break out the score lines with running pliers.

Diamond Tech International One Year Warranty

The Easy Cut Lens Cutter™ is warranted to the original purchaser for one year from the original purchase date. This warranty is against defective materials or workmanship but does not include damage due to neglect, improper use or any other cause not attributed to defects in material or workmanship.

Replacement Part

#512 Easy Cut™ Cutting Wheel

